




CABINET PARTS

29" ELECTRIC DRYER

For Model: LER6611PQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: LER6611PQ0
(Designer White)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|--------------------------------------|----------|---------------------------|------------|----------|---|------------|----------|---|
| 1 | | Literature Parts | 13 | 3357011 | Screw, 10–16 x 1/2 | 36 | 3393549 | Door, Front |
| | 8535829 | Installation Instructions | 14 | 8541401 | Spring, Door (2) | 37 | 690270 | Handle, Door |
| | 8533770 | Sheet, Cycle Feature | 15 | 3394083 | Clip, Front Panel (2) | 38 | 3406129 | Seal & Bearing Assembly |
| | 8522243 | Use & Care Guide | 16 | 3392100 | Foot, Dryer | 39 | 279393 | Terminal Block Kit (For Terminal Block) |
| | 8528187 | Wiring Diagram | | 279810 | Foot – Optional (Extended Length Package Of 2) (Not Included) | 40 | 3393008 | Screw, 10–16 x 1/2 |
| Following May Be Purchased | | | 17 | 279318 | Terminal, Tinned & Brass (3) (Includes Illus. 39) | 41 | 3397659 | Block, Terminal |
| DO-IT-YOURSELF REPAIR MANUALS | | | 18 | 8530603 | Cabinet (Includes Illus. 4) | 51 | 238088 | Hinge, Top (2) |
| | 677818 | Dryer | 19 | 98234 | Clip, Ground | 53 | 691366 | Idler & Pulley Assembly |
| 2 | 343641 | Screw, 10–16 x 1/2 | 20 | 690363 | Lock, Front Top (2) | 56 | 8066065 | Belt, Drive |
| 3 | 693995 | Screw, Hex Washer Head | 21 | 695620 | Panel, Front | 57 | 348780 | Base, Motor |
| 4 | 8541400 | Bracket, Cabinet | 23 | 685203 | Clip, Felt Pad (3) | 58 | 3400500 | Bolt, 5/16–18 x 3/4 |
| 5 | 3396795 | Cover, Terminal Block | 24 | 3389441 | Catch, Door Assembly | 59 | 3394341 | Pulley, 60 Hz. |
| 6 | 342043 | Screw, 10–32 x 3/8 | 26 | 337189 | Clip, Hinge (2) | 62 | 8538262 | Motor Assembly 60 Hz. |
| 7 | 3396805 | Panel, Rear | 27 | 694091 | Screw, 8–18 x 3/8 | 63 | 660658 | Clamp, Motor |
| 8 | 8546676 | Clip, Door Spring | 28 | 8066056 | Hinge, R.H. | 64 | 3404162 | Clamp, Motor (W/Shield) |
| 10 | 3406107 | Door Switch Assembly | | 8066057 | Hinge, L.H. | 67 | 3390731 | Seal, Door |
| 11 | 697773 | Screw, 6–20 x 7/8 | 33 | 696144 | Strike, Door | 68 | 697776 | Screw, 10–32 x 5/8 (External Ground) |
| | | | 35 | 695737 | Door, Rear | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LER6611PQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LER6611PQ0
(Designer White)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|------------------------------|------------|----------|--------------------|------------|----------|-----------------------|
| 1 | 8274261 | Panel, Rear Console | 10 | 8557857 | Screen, Lint | 30 | 357213 | Nut, Push-In (2) |
| 2 | 8539888 | Wire, Jumper (PTS to Buzzer) | 11 | 8536939 | Clip, Spring | 32 | 8299869 | Harness, Wiring |
| 3 | 694419 | Buzzer | 12 | 8533971 | Screw, 8-18 x 5/16 | 33 | 3404233 | Switch, Push-To-Start |
| 4 | 8271365 | Cap, End (L.H.) | 13 | 688983 | Screw, 8-18 x 5/8 | 34 | 8544955 | Timer Knob Assembly |
| 6 | 388326 | Screw, Console | 14 | 8533951 | Screw, Grounding | 35 | 8544935 | Knob, Control |
| 7 | 693995 | Screw, Hex Head | 16 | 8557930 | Top | 36 | 3936144 | Connector |
| 8 | 8271359 | Cap, End (R.H.) | 18 | 94614 | Terminal | 37 | 8271418 | Bracket, Control |
| 9 | 3395683 | Housing, Connector (Motor) | 21 | 8299778 | Timer, 60 Hz. | 38 | 8545981 | Panel, Control |
| | | | 23 | 3394427 | Clip, Harness | | | |
| | | | 29 | 3390646 | Screw, 8-18 x 5/16 | | | |

OPTIONAL PARTS (NOT INCLUDED)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

ACCESSORY PARTS

279948 Kit, Dryer Repair
8522199 Kit, Dryer Vent Testing
3404351 Dry Rack

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray

PAINT, BULK (1 qt.)


799344 White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: LER6611PQ0

(Designer White)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------------------|
| 1 | 348368 | Lint Chute Assembly |
| 2 | 489463 | Screw, 8-18 x 5/8 |
| 3 | 3388703 | Washer-Support |
| 4 | 347139 | Seal, Lint Chute |
| 5 | 90767 | Screw, 8-18 x 3/8 |
| 6 | 696302 | Shield, Exhaust |
| 7 | 3392519 | Thermal Fuse |
| 8 | 3387134 | Thermostat, Internal-Bias |
| 9 | 3977393 | Thermal Cut-Off (Includes Illus. 15) |
| 10 | 694089 | Wheel, Blower (Includes Illus. 22) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---|
| 11 | 8557384 | Housing, Blower |
| 12 | 8066155 | Clip |
| 13 | 343641 | Screw, 10-16 x 1/2 |
| 14 | 8541818 | Box, Heater |
| 15 | 3977767 | Thermostat, 221°F (105°C) |
| 16 | 3977373 | Bracket, Drum Light |
| 17 | 3403585 | Element, Heater |
| 18 | 3403634 | Socket Assembly |
| 19 | 279457 | Wire Kit, Terminal (For Heater Element Wiring Harness Repair) |
| 20 | 3406124 | Bulb, Light |
| 21 | 3402841 | Lens, Drum Light |
| 22 | 3394196 | Seal, Blower |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------|
| 23 | 487909 | Screw, 8-15 x 1/2 |
| 24 | 8066086 | Drum Hole Plug |
| 25 | 3390647 | Screw, 8-18 x 1/2 |
| 41 | 690997 | Ring, Tri |
| 42 | 3399506 | Shaft, L.H. |
| 43 | 3399507 | Shaft, R.H. |
| 44 | 3397588 | Roller, Support |
| 46 | 348197 | Washer, Support |
| 47 | 3359452 | Nut, 3/8-16 |
| 48 | 3403493 | Bulkhead |
| 62 | 692526 | Ring, Bearing |
| 63 | 97787 | Screw, 11-16 x 3/4 |
| 66 | 3406130 | Seal, Rear Drum |
| 67 | 695587 | Drum Assembly |
| 68 | 692490 | Baffle, Drum (2) |
| 69 | 3976434 | Bracket, Support |
| 70 | 90296 | Clip |
| 71 | 3403636 | Baffle, Drum (1) |
| 73 | 339956 | Seal |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST